


CUSTOMER INFORMATION REPORT


Topic: Proper usage of MAG wire offered in the drum package





Conical part of the flange should look up



The part of the spiral that is stated in the drum should not be long



The wire should come from the center of the flange



The fixing bar or any other material should not be left in the drum